


Essentials for every lifestyle.



IB70/100 Remote Control and temperature/voltage monitor



Features - *The remote is a replica of the fridge display and controls and allows:--*

- Wireless Control and readout for both compartments in the fridge/freezer
- Wireless Control of normal and boost compressor speeds
- Wireless Control of the Voltage cut-out
- Wireless readout of the true Voltage the fridge/freezer is receiving

Note: The remote display will automatically update every 2 minutes.

Instructions

1. Connect fridge/freezer to a power source
2. Connect the Remote Control to a power source at a maximum distance of 15 meters, line of sight, from the fridge/freezer

Note:-

- 1: The remote should connect to the fridge/freezer within 30 seconds.
- 2: If the remote does not connect within 30 seconds, disconnect both the fridge and the remote from power for 2 minutes and start again at step 1.

Note: *If there is another similar fridge/freezer within 15 meters, your remote may connect to that fridge/freezer. To resolve this move the other fridge/freezer further away or unplug it while your remote is connecting to your fridge/freezer.*

The remote is a replica of the fridge display and controls and operates in the same manner and can control the same functions. Please refer to the fridge/freezer manual for instructions on how to control the fridge/freezer.



Excellence in portable fridge freezers and iceboxes.