

Sundaya DCS Cabling System

How to wire up a Broco Switch & A-Light



DCS Cable

All Sundaya DCS cables have a 'square' shaped positive and a 'round' negative wire, both joined together in a pair. The 'square' positive is also marked with a '+' symbol at regular intervals. DCS cable is for 12 V DC only.

A-Light

Strip about 1cm of insulation back from the wire, detach the black cover on the pull-switch end of the light and feed the wire through from the back. Screw down the positive to the '+' terminal, and screw down the negative to the '-' terminal.



Broco Switch

Attach the S-con to the wire running to the light, and position the 'branch' wire that will travel to the switch. At the end of the 'branch' wire, strip back the insulation by about 1.5cm. Press down on the small button next to the hole intended for each wire, and insert the wire. Release the button, and the wire will be clamped in place.



RAINBOW POWER COMPANY LTD

Designers and Installers of Solar Systems since 1987

1 Alternative Way (PO Box 20240)

tel: (02) 6689 1430

international: +61 2 6689 1088

email: sales@rpc.com.au

A.B.N. 74 003 323 420

Nimbin NSW 2480 Australia

fax: (02) 6689 1109

international: +61 2 6689 1109

website: www.rpc.com.au

Lic:198555C (NSW). 69172 (Qld)